



For questions please call us at (616) 396-1142


5. Slide (1) center panel into the groove in the intermediate panel with holes toward the bottom of the bookcase.




7. Repeat steps 2-6 until all adders have been set up. Then, screw the bottom screw of (6) 90-degree brackets into each of the remaining boxes using (6) #10 X 0.625" screws. Tighten to a torque of 30-35 in-lbs.




6. Attach the center panel with (2) 5/16 X 3" hex bolts, (2) flat washers, and (2) flanged nuts using the two larger holes on the panel and boxes. Tighten to a torque of 50-60 in-lbs.




8. Align the right hand end panel to the last bottom boxes with the center panel in the end panel groove. Attach the end to the bottom boxes using (4) 5/16-18 X 1.5" hex head bolts and (4) washers. Hand tighten.





For questions please call us at (616) 396-1142



For questions please call us at (616) 396-1142







For questions please call us at (616) 396-1142