## CARE AND MAINTENANCE

# CARE OF LAMINATE, METAL, PLASTIC FINISHES AND CHEMICAL RESISTANT PHENOLIC RESIN WORKSURFACE

Wipe product with a damp cloth to remove general soil and water-borne stains. If needed, use a nonabrasive, all-purpose cleaner suitable for hard surfaces such as Soft Scrub®, Windex®, Glass Plus®, Formula 409®, Fantastic®, or Mr. Clean® followed by a clean water rinse and dry immediately. Abrasive or harsh chemicals may discolor or mar the finish. Also, avoid abrasive cloths and sponges like Mr. Clean® Magic Eraser. Remove water spills immediately. Do not place heat producing items directly on laminate or chemical resistant phenolic resin surfaces as it may mar the finish. To sanitize surfaces, use a disinfecting, disposable wipe cloth like Clorox®.

## CARE OF MAPLE BLOCK WORKSURFACES

Dust with a cloth slightly dampened with water. Clean tops with warm, soapy water and dry with rag or towel to remove any standing water on surface. Furniture wax can be applied periodically to bring back some of the luster which may be lost over the years.

Maple block is a natural material. Variations in grain and color are part of its natural character. Wood products will develop a beautiful patina over time which will modify its initial color. Exposure to sun will accelerate this process. Keep wood products at a relatively constant temperature and humidity.

# CARE OF PAGES™ MARKERBOARDS AND WHITE MARKERBOARD SURFACES

Use non-toxic dry erase markers and microfiber cloths to erase. Clean the boards with soap and water only, using a lint-free soft cloth. Avoid harsh chemicals, especially ones that contain ammonia that will damage the finish.

#### **CARE OF EDGEBAND**

Use a mild liquid detergent. After cleaning, wipe the edges with a cloth dampened with warm water and dry immediately.

#### CARE OF FABRIC

**SILVERTEX** contains an antimicrobial agent. It is safe for diminishing odors and helps control bacterial growth. Cleaning instructions vary based on stain type:

**GENERAL:** Clean with damp cloth.

**STAIN TYPE:** Felt tip marker, crayon, chocolate, suntan lotion, hair/body oils. Clean with 1:1 mix of lvory™ soap and water.

**STAIN TYPE:** Blood, urine, feces, oil-based paint, tar, asphalt. Clean with a 1:1 mix of ammonia and water, or a 1:4 mix of bleach and water.

**STAIN TYPE:** Other stains: Clean with a 1:1 mix of isopropyl alcohol and water. If stain persists, use straight alcohol.

## **CARE OF PLASTIC**

When cleaning the Evoke's plastic shell, use warm water, a dishsoap-based cleaner, and a soft cloth. If disinfecting the shell, use an alcohol-based spray or wipe.